

ALUMINIUM COVER ASSEMBLY MANUAL

In the case of standard width cookers



1. Install the mounting strip to the countertop.

2. Cut the aluminum cap on the size corresponding to the length of cooker.

3. Cut the countertop strip so, that was established in it the 4 cm gap under the aluminum cap.

4. The resulting two strips insert into the aluminum cap from both sides in such a way, that in the middle is the interval of 4 cm.

5. **Avoid reversing of strip - this may result in scratches!**

6. Install countertop strip along with the imposed cap on fixing strip.

ALUMINIUM COVER ASSEMBLY MANUAL

For cookers with a width exceeding 80 cm.

	1. Install mounting strip to the countertop.
	2. Cut the aluminum cap on the size corresponding to the length of cooker.
	3. Cut the countertop strip section 8-10 cm in length.
	4. Insert the cut section of the strip in the cap so that it is in the middle of the cap.
	5. Other strips cut and insert in such a way, as to keep a distance of 4 cm on both sides of the short segment of strip.
	6. Avoid reversing of strip - this may result in scratches!
	7. Install countertop strip along with the imposed cap on fixing strip.